

SIMPLE BAR CART

What you need:

- Sanding block
 - Rag
 - Valspar Furniture Paint
 - Stir stick
 - Paintbrush
 - Small roller (optional)
 - Paint tray (optional)
-

What you do:

1. Prep the cart. Sand and wipe down smooth surfaces. Remove casters.
2. Give the paint a stir.
3. Apply an even coat, starting in the corners with a brush, then rolling on the large, flat surfaces.
4. Let it dry for 24 hours. The first coat might not be perfect, but don't worry.
5. Add a second coat.
6. Give it another 24 hours.
7. Replace the casters. A new set can make all the difference.
8. Cheers to a job well done.

ACTIVE TIME 1-2 HOURS **TOTAL TIME** 48 HOURS

valspar

Hematite
4006-2C

