

MODERN BATHROOM CABINET

What you need:

Sanding block
Rag
Screwdriver
Painter's tape
Valspar Cabinet Enamel
Stir stick
Paintbrush
Small roller (optional)
Paint tray (optional)

What you do:

1. Prep the cabinet. Sand and wipe down smooth surfaces. Remove hardware.
2. Any hardware that you can't remove, like hinges, cover with painter's tape.
3. Give the paint a stir.
4. Start with the details. Paint detailed woodwork first, then fill in the rest with a brush or roller.
5. Let it dry for 24 hours. With darker colors especially, you'll need Step 6.
6. Add a second coat.
7. Give it another 24 hours.
8. Replace the hardware.
9. Draw a bath, you're done.

ACTIVE TIME 1-2 HOURS **TOTAL TIME** 48 HOURS

valspar

Moon Shade
4006-4C

