

DETAILED DRESSER

What you need:

Sanding block
Rag
Screwdriver
Painter's tape
Valspar Furniture Paint
Stir stick
Paintbrush
Small roller (optional)
Paint tray (optional)

What you do:

1. Prep the dresser. Sand and wipe down smooth surfaces. Remove hardware.
2. Tape inside each drawer.
3. Give the paint a stir.
4. Start with the details. Paint detailed woodwork first, then fill in the rest with a brush or roller.
5. Let it dry for 24 hours. Don't freak out if it's not perfect. That's what Step 6 is for.
6. Add a second coat.
7. Give it another 24 hours.
8. Replace the hardware.
9. Admire your hard work.

ACTIVE TIME 1-2 HOURS **TOTAL TIME** 48 HOURS

valspar

Pacific Pleasure
5009-10

