

# RETRO METAL CABINET

---

## What you need:

- Rag
  - Screwdriver
  - Painter's tape
  - Valspar Bonding Primer
  - Valspar Cabinet Enamel
  - Stir stick
  - Paintbrush
  - Small roller (optional)
  - Paint tray (optional)
- 

## What you do:

1. Prep the cabinet. Wipe it down and remove hardware.
2. Tape any surface you don't want to paint.
3. Brush on metal primer and let dry for 45 minutes.
4. Stir up your Cabinet Enamel.
5. Cover it with color.
6. Let it dry for 24 hours. It's OK if the color's not perfect. That's what Step 7 is for.
7. Add a second coat.
8. Give it another 24 hours.
9. Replace the hardware.
10. Admire your hard work.

**ACTIVE TIME** 1-2 HOURS **TOTAL TIME** 49 HOURS

valspar

Salmon Rose  
2003-3C

