

# ANTIQUE SEWING CABINET

---

## What you need:

Sanding block  
Rag  
Screwdriver  
Valspar Cabinet Enamel  
Stir stick  
Paintbrush  
Small roller (optional)  
Paint tray (optional)

---

## What you do:

1. Prep the cabinet. Sand and wipe down smooth surfaces. Remove hardware.
2. Take out the drawers for easy painting.
3. Give the paint a stir.
4. Apply an even coat. Don't forget the legs and drawers.
5. Let it dry for 24 hours. It may not be perfect yet, but that's what Step 6 is for.
6. Add a second coat.
7. Give it another 24 hours.
8. Replace the hardware. New knobs give it a whole new look.
9. Put your feet up and enjoy.

**ACTIVE TIME** 1-2 HOURS **TOTAL TIME** 48 HOURS

valspar

Pale Bloom  
7002-8

