

OLD SCHOOL TV TRAYS

What you need:

Sanding block
Rag
Valspar All-Purpose Primer
Valspar Furniture Paint
Stir stick
Paintbrush
Paint tray (optional)

What you do:

1. Prep the trays. Sand and wipe down the tops and edges of each tray.
2. Brush on a coat of primer and let dry for 45 minutes.
3. Give the paint a stir.
4. Apply a smooth, even coat of paint. For extra fun, use a different color on each.
5. Let them dry for 24 hours. It's OK if they don't look awesome now, we've still got Step 6.
6. Add a second coat.
7. Give them another 24 hours.
8. Make yourself some dinner and kick back.

ACTIVE TIME 1-2 HOURS **TOTAL TIME** 49 HOURS

valspar

Laguna Green
5007-10B

